


How to Purchase Resident Advantage® Card Using Cash (Only \$5, \$10, \$20 Bills Accepted):

One Bill Per Transaction

1. Press **"2"** to purchase card. (Transaction may be cancelled by pushing * button).



2. Insert \$5 bill into the bill acceptor.



3. Remove new laundry card. (Card will have \$0.00 balance.)



4. Insert card back into machine to add more value.

