How to Add Value to Existing Resident Advantage® Card Using Cash:

One Bill Per Transaction

1. Select Action. Push **1** to **Add Value** to your card.




2. Select Payment. Push **4** to select **Cash**.



3. Insert your Laundry Card.



4. Insert bill (\$5, \$10 or \$20 bill only.) Keep in mind maximum possible card value is \$50



5.
Remove Card.
(Transaction may be cancelled at any time by pressing the CANCEL button.)

